

### Preparation

Before you begin, ensure there is a 6mm clearance all around the outside of your window beading to allow enough room for the Perfect Fit framework. Also check that the seals of your window frame do not protrude over the glass more than 6mm and that they are compressible. You can then take a bead to bead measurement.

If your seals are not compressible (solid) and do not protrude over the glass by more than 6mm you can then take a seal to seal measurement.



### Measuring Instructions


#### Step 1 - Measure glass size

Measure the width and the drop of your window size accurately. We recommend that you measure in both corners and the middle of your window and use the smallest size taken.



#### Step 2 - Measure window depth

Measure the depth of the window using a ruler/straight edge and a tape measure. This gives you the measurement from the face of the window frame to the glass (this is normally 18mm, 20mm or 24mm) and will determine the size of the window fixing brackets you will use.



### Installation

There is a simple assembly procedure to follow before installing the blind in the Perfect Fit frame.

1. Carefully unwrap the blind components and unravel all guides and control cords. The top and bottom parts of the frame will be attached together with cable.

Lay out the blind face down on a clean, even surface.

2. Select the left hand frame component and guide onto the exposed arm of the bottom left corner joint.

3. Slide the frame along the arm until secure. Repeat the process on the top left hand corner joint.

Now follow the same procedure for the right hand frame.



4. Once the frame is complete tighten the securing screws attached to each corner joint.



### Additional assembly instructions for Tab Venetian

1. When assembling the side rails you will experience some tension.
2. Ensure that the side cords are free from the corner pieces when assembling the frame.
3. Once the blind and frame is assembled you may need to re-tension the blind before fitting.

### Tensioning guidelines

Only adjust the tension on the screw which is not attached to the spring.

**DO NOT OVERTIGHTEN THE SCREW**




Your blind and Perfect Fit frame is now ready to be fitted



### Operation guidelines

We recommend operating the blind in the following way:



Correct



Incorrect

### Fitting the Perfect Fit Frame to the Window Frame

#### Insert window fixing brackets

1. If required, apply lubricant in the form of washing up liquid to the flat base of the window fixing bracket prior to insertion of the bracket between window and rubber seal. For the correct spacing distance of the brackets (85mm) use a credit card and place it into a corner of the window.
2. Line up the window fixing bracket at the base of the card (or top of the card depending upon which corner of the window you are working) and fit the bracket by pushing it between the glass and the rubber seal on the window.
3. Using the measuring card guarantees a perfect line up for each of the holes in your frame with each of the brackets.

Fit any intermediate brackets accordingly. Clean excess lubricant from window surface prior to fixing frame to brackets.

4. Line up the holes in the frame with the window fixing brackets.



5. Firmly press the frame onto each bracket, one side at a time.



6. Your blind is now installed



Pleated blind



Venetian blind

### Packing pieces for window handles

Blinds fitted to windows with handles may require packing pieces to be inserted between the framework and the handle.

This is to stop the handle from touching the frame when operated. There are two different lengths available.

1. Lift the handle to an upright position and remove the screw caps.



2. Unscrew the handle from the frame



3. Place the packing piece(s) in between the handle and the frame.



4. Re-fit the handle.



### Perfect Fit Removal

1. To remove the frame from the window, raise the blind to a completely open position.



2. Release the frame from each bracket by inserting a flat headed screw driver into the hole and depress against the lip of the brackets.



3. Remove one side at a time to ensure easier removal.

